



No. Order No. Description

1	32-B 015	Side handle
2	48-L 069	Gear Housing
3	48-K 340	Hex nut
4	48-L 106	Pinion/Crown wheel unit
5	48-K 430	Spacer ring
6	48-Q 134	Ball bearing
7	48-L 071	Flange
8	48-M 393	Armature
9	48-Q 004	Ball bearing
10	48-L 090	Bearing seat
11	48-L 092	Vent plate
12	48-S 714	Screw
13	48-L 074	Clutch kit
14	48-L 093	Spacer
16	48-L 933	Intermediate plate
17	48-L 076	Gear flange
18	48-S 510	Screw
19	48-L 077	Grinding spindle
20	48-S 553	Screw
21	30-B 020	Quick nut
	30-B 037	Clamp nut (manual operation)
22	30-B 036	Flange
23	48-L 102	Safety guard

No. Order No. Description

24	48-K 410	Nut
25	48-L 651	Spacer
27	48-L 079	Slider
28	48-L 094	Switch rod
29	48-M 366	Cable clamp
30	48-S 744	Screw
31	48-M 394	Housing cover
32	48-L 083	Cable sleeve
33	48-Z 201	Cord set
34	48-M 395	Field
35	48-M 396	Sensor
36	48-L 139	Motor housing
37	48-L 919	Carbon brush
38	48-L 086	Brush assembly
39	48-L 087	Lead
40	48-M 398	Electronic component
41	48-M 399	Connector
42	48-L 141	Switch
43	48-M 400	Plastic lens
45	48-L 099	Fan
46	48-L 918	Insulating sleeve
47	48-M 403	Spacer
48	48-M 404	Sealing Flange