


**718 only**

<b>No.</b>	<b>Order No.</b>	<b>Description</b>
1	48-Z 201	Cord set
2	48-E 001	Reversing switch
4	48-E 024	Handle
5	48-e 002	Cable sleeve
6	48-E 003	Switch
7	48-S 702	Screw
8	48-E 004	Cable clamp
9	48-S 704	Screw
10	48-S 709	Screw
12	48-E 025	O-ring
13	48-Q 074	Ball bearing
14	48-E 005	Brush holder assembly
15	48-E 006	Carbon brush
16	48-S 664	Screw
17	48-K 131	Washer
18	48-E 007	Motor housing
19	48-S 711	Screw
20	48-E 008	Vent plate
21	48-K 316	Retaining ring
22	48-Q 048	Ball bearing
23	48-K 303	Retaining ring
24	48-E 009	Contact plate
25	48-E 010	Armature
26	48-E 011	Field
27	48-S 712	Screw
28	48-E 068	Gasket
29	48-E 012	Gear housing
30	48-E 013	Slider assembly

<b>No.</b>	<b>Order No.</b>	<b>Description</b>
31	48-E 014	Shift fork
32	48-E 015	Drilling spindle
33	48-Q 075	Ball bearing
34	48-E 016	Spacer
35	48-E 017	Gear
36	48-Q 077	Ball bearing
37	48-Q 222	Needle bearing
38	48-E 018	Shift gear
39	48-E 019	Pinion shaft
40	48-K 025	Key
41	48-E 020	Gear
42	48-E 021	Pinion shaft
43	48-E 022	Gear flange
44	48-E 023	Alignment pin
45	48-Q 048	Ball bearing
46	48-E 063	Side handle
	48-S 552	LH chuck screw
	22-A 072	Keyed chuck
	22-A 202	Chuck key
47	48-E 067	Flange (718 only)
48	48-E 065	Cover (718 only)
49	48-S 665	Screw (718 only)
50	48-E 066	Cable sleeve (718 only)
51	48-E 064	Switch (718 only)
52	48-E 069	Nut (718 only)
53	48-E 070	Plug (718 only)