



No.	Order No.	Description	No.	Order No.	Description
1	48-R 271	Carrying handle	15	48-R 277	Ground outlet (yellow)
2	48-R 287	Stainless steel screw	16	48-R 278	Power outlet (black)
3	48-R 288	Stainless steel nut	17	48-R 279	Front logo plate
4	48-R 289	Stainless steel washer	18	48-R 280	Gasket
5	48-R 272	Housing	19	48-R 281	Transformer 120/230V AC
6	48-R 273	Main logo plate	20	48-R 282	Rear panel
7	48-Z 202	Cord set 120V AC	21	48-R 283	Ground cable
	48-R 292	Cord set 230V AC	22	48-R 284	Power cable
8	48-R 274	Fuse holder	23	48-R 286	Wand holder
9	48-R 290	Fuse 10 amp 120V AC	24	48-R 285	Cleaning wand complete
	48-R 293	Fuse 6 amp 230V AC	25	48-R 294	Electrolyte straw
10	48-R 275	Transformer base	26	48-R 299	Protective cover
11	48-R 276	Front panel	27	48-R 296	Sleeve
12	48-R 105	Switch	28	48-R 297	Stainless steel screw
13	48-R 291	Stainless steel screw	29	48-R 298	Electrolyte tube adaptor
14	48-R 145	Circuit breaker 120V AC	30	54-B 022	Narrow stainless steel insert 90°